



Practice



Let's practice! Make R/C car circuit at a wide and safe location using corner pylons (separately available), empty cans or such. Running fast at straight section and slow down at curved section is a basic speed control technique useful when driving R/C car.


Maintain




When the car is not in use, you should remove the battery from the car.



Completely remove sand, mud, dirt etc.















Metal outside should apply the rust prevention oil.












Store the car and batteries separately when not in use.

Assembly Exploded Diagram













21




22




Rear wave box assembly







23




Front wave box assembly



24




Sale parts view




0066

12 * 5.2 * 0.2 gasket set assembly




0073

Differential shaft assembly



0098

M3*3 Inner hexagonal screw assembly



0102

2.5*10PM screw assembly




0114

2.5*8KM screw assembly




0117

3*8KM screw assembly



1374

USB charging line



0256

3*12PM screw assembly



1669

V2-144001 Remote controller



0422

2 * 6KM screw assembly



0553

2 * 6PB screw assembly




0582

ST2*7PB screw assembly




1153

30T Differential Large Teeth(Hardware) Component




1154

12T Active Teeth(Hardware) Group




1155

24T Differential Large Planetary Teeth(Hardware) Group




1249

car body assembly



1250

Front and rear arms



1251

Front seat assembly



1252


Rear seat assembly



1253

Type C Block Component

Sale parts view




1254

Wave Box Component




1255

Bottom side guard assembly




1256

Ball head support assembly



1257

Anti-collision accessories components




1258

Final-end firmware component




1259

Second floor panel components



1260

Slow down large tooth assembly



1261

Battery partition assembly



1262

Speed gear upper and lower cover assembly




1263

Tiller arm assembly



1264

Motor seat press component




1265

Steering seat press assembly



1266

Hexagonal seat assembly




1267

Front and rear arm sleeve




1268

Switch to clutch component




1269

Front tire assembly



1270

Back tire assembly



1271

10T Differential Asteroid Teeth(Hardware) Group



1273


Shock absorber spring assembly




1274

1.5*9.35 Optical axis


Sale parts view




1*9 Optical axis




2.5*40 Optical axis



2*26 Optical axis




Shock absorber shaft component




Buffer spring assembly




Dog bone assembly




Universal drive shaft assembly



Rear Wheel Cup Component



Front Wheel Cup Component




Cross shaft assembly



Universal cup spring assembly




Steering gear lever assembly



Short pull bar assembly




Long pull bar assembly



Steering column assembly




Steering column sleeve component




Ball Head Component



Central Transmission Axis Component



6 * 2.7 flange sleeve assembly




6 * 5.2 flange sleeve assembly


Sale parts view




Ball bearing assembly




Shock absorber cylinder assembly



Shock absorber cap assembly



Regulate Ring Component



Spring seat assembly




Shock absorber assembly



Motor Block Component




Steering connecting rod assembly



Front swing arm reinforcement module




Backswing arm reinforcement module




Rudder assembly




Motor components



Differential




Receiver board assembly



Type 0 assembly




Coaxial component




Shock absorbers



ST2.6*5KB screw assembly























Car shell components



Heat Discharge Group

Sale parts view

<p>1337</p> 	<p>1338</p> 	<p>A202-04</p> 	<p>A202-15</p> 
<p>4.9*13.6Ball Head screw assembly</p>	<p>4.9*10.6Ball Head screw assembly</p>	<p>4.0*9.5Ball Head screw assembly</p>	<p>ST2*8KB screw assembly</p>
<p>A303-39</p> 	<p>A929-86</p> 	<p>A949-22</p> 	<p>A949-35</p> 
<p>ST2.6*6PWB6 screw assembly</p>	<p>M3*5 Inner hexagonal screw assembly</p>	<p>Magic paste group</p>	<p>Ball bearings 7 * 11 * 3 groups</p>
<p>A949-38</p> 	<p>A949-43</p> 	<p>A949-49</p> 	<p>A959-B-15</p> 
<p>ST2.6*6PB screw assembly</p>	<p>2.5*6PWM6 Screw assembly</p>	<p>M3 Loose nut assembly</p>	<p>Motor teeth 27T group</p>
<p>A959-B-23</p> 	<p>L959-54</p> 	<p>L959-57</p> 	<p>L959-58</p> 
<p>Battery assembly</p>	<p>ST2.6*8KB screw assembly</p>	<p>ST2.6*8PB screw assembly</p>	<p>ST2.6*10PB screw assembly</p>
<p>1452</p> 	<p>1389</p> 	<p>1453</p> 	<p>1656</p> 
<p>M3 flange nut</p>	<p>3 * 20pm Cross round head machine screw</p>	<p>2*4PWM5 Cross round head machine screw</p>	<p>2.5*8PWM6 Cross round head machine screw</p>